

Aastra Business Communication Systems



Aastra 612dQuick User's Guide

AASTRA Aastra 612d

English



Document designation

- · Document number: eud-1466 / 1.1
- Copyright © 05.2012 Aastra Technologies Limited

General information

Your device has been supplied with a quick user's guide, safety information and, where applicable, with other device-specific information. You will find this and other documents for your device at www.astra.com.or.@: www.astra.com/docfinder.

Communication systems

Your telephone can be used with different communication systems; therefore, the operation differs according to system. The availability of the functions, features, key assignments and products also depends on the communication system. Mark your communication system as follows:

	Aastra 5000 □, Aastra X Series □, NeXspan □
2	Aastra 800 □, OpenCom 100 □, OpenCom 1000 □
	OpenCom 1000 □
3	SIP-DECT® □
4	Aastra 400 □, Aastra IntelliGate □
(5)	MX-ONE SIP-DECT® □

Keys

System

Call kev:

- · Set up a connection.
- · R-key function.

Redial list:

- ①/②/③/⑤: Press and hold down the Call key.
- · @: Press the Call key.

End key:

- · Cut connection.
- Exit editor without changes.
- In a menu: Back to idle state.
- Press and hold down: Activate/deactivate phone.

۵	Loudspeaker key vate hands-free		/dea	ct

Softkeys: Executes displayed function above key.

Navigation keys:

- In a menu: Scroll forward and backward.
- In a list: Navigate.
 - In idle: Call up stored functions.
- Correction key: Delete the last character or go back one step in the menu.

⊕ ⊖ "Plus / Minus" side keys: Adjust current connection volume.

* Star key: Press and hold down to activate/deactivate ring tone.

③/⑤: To switch between digits/letters and upper/lower case.

Hash key: Press and hold down to lock keypad.

Display symbols (selection)

Radio link quality
(4 signal bars: good, 1 signal bar: bad)

State of charge

Microphone off

Ring tone off

⋙

More options available

New message in the voice mailbox

①/④: New text messages

①/④: Read text messages



LED indicator

Green	 Flashes fast: Incoming call, enquiry call. Lit: Handsfree on.
Red	Flashes slowly: • ①/②/③/⑤: New entries in the info area, alarm/appointment. • ⑥: New voice mail. Flashes fast: • Outside the system's service area.

Lit: Battery charging.

General characteristics

- Headset connection via a cable
- Protection class IP 50

Orange

Installation

Installing the battery

Push the battery cover downwards until it is released from the lock, then take it off. Insert the battery with the contacts downwards. Replace the battery cover and push it upwards until it locks.

Connection

Call kev.

- · Taking a call: Press the Call key.
- To end the connection: Press the End key.
 To make a call from lists (redial list, call lists, phone book): Call up depends on the communication system, select an entry, then press the

Phone book/Name selection

①/②/③/⑤: Press the navigation key upwards or downwards. Enter name or first letter of the name. If necessary select entry. To dial: Press the Call key.

Tress each of the corresponding keys once for the first few letters of the name you are looking for. Separate the first name and the surname with the #-key, e.g. "no s" (6 6 # 7) for Nobel Stephen. Press the ABC softkey. Press the Call key; the selected entry is called.

During a connection...

Enquiry

- ①/②/③· Enter R and call number
- 3: Enter R and call number then press hash.4: Press the Enquiry or Call key then enter the call number.

To end the enquiry call

- ①: Enter R and 1 [].
- ②/③: Press >>>, select **Release call** and confirm with **Ok**. press R.
- 4: Press the End call softkey.

Brokering

- Switches between two callers without interrupting the calls. You are making/taking a call:
- ①: Enter R and 2 []. ②/③: Press R.
- Tress the Brokering softkey.
- ⑤: Press 2 [].

To set up a conference

- Connects several callers for a conference call. A call participant is put on hold (see "Enquiry"): ①/⑤: Enter R and 3 [].
- ②: Press >>>, select **3 party** and confirm with **Ok**. ④: Press the **Conference** softkey.
- Leaving a conference call: Press the End key.

To set up a connection

- ①/②/③/⑤: Press R, enter call number and press End kev.
- Tess the Enquiry softkey, enter call number and press the Connect softkey.

To take a call during a conversation (Call waiting)

- ①: Enter R and Star 10 [].
- 2/3: Press R.
- ④: Press the Call waiting softkey.

Callback

The person is busy or does not answer.

①: Enter R and 5 [].

- ②: Press >>>, select **Callback** and confirm with
- Ok.
- Tress the Callback softkey.
- ⑤: Press 6 [].



Exclusion of Liability

Aastra® is a registered trademark of Aastra Technologies Limited. Technical modifications and product availability subject to change without notice.

Copyright @ 2012 Aastra Technologies Limited

